


QUICK TREAD EDGE[®]



Automatic Tread Inspection System

OPERATIONS MANUAL





1

Drive across tread depth sensors at a speed of 2 - 8 mph (3.2 - 12.8 kph).





2

Cameras analyze all four tires. Results are compiled and stored automatically.



3

View printout or FlightBoard for results.



For Your Safety

This manual provides operation instructions for the Quick Tread Edge system (console, sensors & software).

Hazard Definitions (Watch for these symbols below)



CAUTION: Hazards or unsafe practices, which could result in minor personal injury or product or property damage.



WARNING: Hazards or unsafe practices, which could result in severe personal injury or death.



DANGER: Immediate hazards, which will result in severe personal injury or death.

These symbols identify situations that could be detrimental to your safety and/or cause equipment damage.

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before operating Quick Check Drive®. Read and follow the instructions and warnings provided in the service, operation and specification documents of the product.



Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Do not operate equipment with a damaged cord or equipment that has been dropped or damaged until a Hunter Service Representative has examined it.

To reduce the risk of electrical shock, do not use on wet surfaces or expose to rain. To reduce the risk of fire, do not operate equipment near open containers of flammable liquids (gasoline).

Read and follow all caution and warning labels affixed to your equipment and tools. Misuse of this equipment can cause personal injury and shorten the life of the unit.

Keep all instructions permanently with the unit. Keep all decals, labels, and notices clean and visible.

Power off the unit and clean as required with a damp cloth. Use equipment only as described in this manual. Do not modify the unit or remove protective housings and covers. No user serviceable parts inside.

Service is to be performed only by Hunter factory authorized personnel.

Do not allow laser light to be directed or reflected toward people or reflective objects. Do not operate the unit if it requires service or if protective covers and housings are damaged.

Using this equipment in any manner other than specified by Hunter may disable its safety features.

Save these instructions.

Laser Activation


- Vehicle drives over **trigger 1** turning on laser.
- Vehicle drives over **trigger 2** takes picture of the tire & tread and then turns the lasers off.

Decal Information and Placement


Top View

Decals **128-1566-2** indicates the locations of laser apertures.

Decal **128-1565-2** indicates laser radiation is present.




The Class 3R laser apertures are located inside the sensor assembly



Sensor View

FDA standards for Class 3R laser compliance are shown on Decal **128-1795-3**.



A collection of safety labels for the laser product. At the top is a yellow triangular laser radiation warning symbol. Below it is a yellow rectangular label with the following text: 'LASER LIGHT', 'AVOID DIRECT EYE EXPOSURE', 'CLASS 3R LASER PRODUCT', '638/658nm <7mW CW', 'EN/IEC 60825-1 2014 (2007 USA)'. Below that is another yellow rectangular label with the following text: 'RAYON LASER', 'EVITER TOUTE EXPOSITION DIRECTE AVEC LES YEUX', 'PRODUIT LASER DE CLASSE 3R', '638/658nm <7mW CW'. At the bottom are two white rectangular labels with black text. The first one reads: 'Complies with FDA performance standards for laser products except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.' The second one reads: 'Conforme aux normes de performance de la FDA pour les produits laser sauf les déviations conformément à l'avis de laser no. 50 du 24 Juin, 2007.'

A manufacturer's identification label is also on the rear of each tower.

MODEL NO.		
PART NO.		
HUNTER Engineering Company		
11250 Hunter Drive Bridgeton, MO 63044 USA		
ERC		
VAC ~	AMPS	SERIAL NO.
	PHASE	HERTZ
SERIAL NO.		

Specific Precautions/Optical Scan Laser

The Optical Scan Laser is a class 3R laser designed to measure tread depth. The laser is not a field serviceable part. No maintenance is to be performed on the laser.

This laser product is designated as Class 3R during all procedures of operation.

Wavelength: 638/658nm

Laser power for classification: <7 mW

This product is properly classified at 7mW due to the laser's "extended source".

Emission type: CW

Beam Diameter: <3 mm at aperture

Divergence: <1 mRad

Fan angle: 60°



Develop skills and knowledge

EXCEL WITH HUNTER TRAINING



Live On-Site Training

All Hunter Training classes are led by ASE-certified instructors and all training material is kept up-to-date through a rigorous curriculum review process.

YouTube Video Tutorials

Product-focused videos explaining features and processes

Hunter University

Self-driven eLearning courses designed for all student levels



hunter.com/training



Hunter Learning Channel



Because of continuing technological advances, specifications, models and options are subject to change without notice.

PowerSlide and WinAlign are registered trademarks of Hunter Engineering Company. The PowerSlide logo is a trademark of Hunter Engineering Company.

HUNTER
Engineering Company
www.hunter.com